

ULTRACOLOR T 67 S 42 telecommander **ULTRACOLOR T 56 S 42 telecommander ULTRACOLOR tc T 7670 Bregenz ULTRACOLOR tc T 8670 S ULTRACOLOR T 67 S 43 telecommander ULTRACOLOR T 56 S 43 telecommander** 

Schema di servizio · Service circuit diagram · Documentation technique Service-Einstellungen · Regolazioni di servizio · Service Adjustments · Réglages de service




Erklärung der im Schaltbild verwendeten Symbole. Spiegazione dei simboli usati in questo schema. Explanation of the symbols used in the circuit diagram. Légende des symboles utilisés dans le schéma de montage.



Bauteilekennzeichnung der Funktionsstufen Codice componenti con sigla dello stadio Signification of components of the stages Désignation des composants et des circuits

RC, CC, DC, TC, LC	etc.	→ Chroma	(PAL-Decoder, Decoder PAL)
RF, CF, DF, TF, LF	etc.	→ Frame	(Vertikal, verticale)
RL, CL, DL, TL, LL	etc.	$\rightarrow$ Line	(Horizontal, orizzontale)
RP, CP, DP, TP, LP	etc.	→ Power	(Netzteil, alim. rete)
RS, CS, DS, TS, LS	etc.	$\rightarrow$ <b>S</b> ound	(Audio)
RV, CV, DV, TV, LV	etc.	→ Video	(Video)

SABA SERVICE-ORGANISATION Anderungen vorbehalten! Best.-No. 4900.016.820 VSO 1083370a T Con riserva di modifichel Teil-Nr. 82610.000.91




FF 217 - T 67 S 42


FF 218 - T 56 S 42 FF 219 - T 7670


FF 220 - T 8670 S

FF 225 - T 67 S 43

FF 226 - T 56 S 43







1R-Vorverstärker

No. 81850 352 00

8 Telecommander TC 356

